



HEAT CONCEPT

MERCI D'AVOIR ACHETÉ LES PRODUITS HEAT CONCEPT.
NOTICE A LIRE ATTENTIVEMENT AVANT UTILISATION

ATTENTION : IL EST IMPERATIF D'UTILISER UNIQUEMENT LE CHARGEUR FOURNI AVEC LE PRODUIT POUR RECHARGER VOS BATTERIES

IMPORTANT MISE EN SERVICE :

1) Il est nécessaire de charger complètement les batteries avant la 1ère mise en service.

- Branchez le chargeur à une prise (le voyant de charge LED s'allume en **VERT**)

- Branchez ensuite les 2 batteries au chargeur, la charge commence automatiquement et le voyant de charge reste allumé pendant la charge. (La LED devient **ROUGE** ceci indique que vos batteries doivent être chargées)

2) La durée de la charge varie de 2 à 4 heures selon le niveau de charge de la batterie.

- Lorsque la batterie est complètement chargée, la charge s'arrête automatiquement et la LED du voyant de charge redevient **VERTE**.

3) Débranchez les batteries du chargeur et raccordez à nouveau les batteries au connecteur du gant ou des couvre-chaussures, placez chaque batterie dans les emplacements prévus et fermez correctement la poche.

4) Appuyez + de 3 secondes sur la touche pour allumer ou éteindre le système de chauffe.

UTILISATION DE VOS PRODUITS HEAT CONCEPT

Nous vous conseillons d'allumer en mode **LED VERTE**, vos gants sans les enfiler 5 min avant de prendre la route afin que les gants préchauffent et que vos mains soient parfaitement protégées du froid du début à la fin de votre sortie.

Appuyez + de 3 secondes pour allumer ou éteindre la chauffe.

Au milieu de votre sortie passez en mode **ORANGE** (chauffe un peu plus intense que le mode **VERT**) et en fin de sortie quand vous sentez que la température du gant est moins élevée passez en mode **ROUGE** pour terminer votre entraînement avec les mains au chaud.



LED VERTE = CHAUFFE MINIMUM
LED ORANGE = CHAUFFE INTERMEDIAIRE
LED ROUGE = CHAUFFE MAXIMUM

Dès votre retour remettez vos batteries en charge.

AVERTISSEMENT :

En cas de pluies importantes, nous vous conseillons de ne pas utiliser le système de chauffe.

Pourcentage de charge batterie



4 barres rouges = 100%
3 barres rouges = 75%
2 barres rouges = 50%
1 barre rouge = 25%

- Garantie de 2 ans.

Info BATTERIE :

- Batteries Polymères de lithium 7,4 V : LI-PO 2200 ah
- DCP : DC 8,4V 1200mA
- Puissance de sortie MAX 15W

Stockage BATTERIE :

- Stockez les batteries dans un endroit frais et sec.
- Ne pas exposer au soleil, ou à une source de chaleur
- Prévues pour 500 cycles de charge
- Batterie de rechange disponible en option.

Info CHARGEUR :

- Chargeur INPUT AC100/240 V (50 / 60 Hz-1.0A)
- Chargeur OUTPUT DC8.4V / 1200 mA

- Batteries rechargeables amovibles (Livrées avec chargeur secteur).

- **Pensez à les recharger tous les 3 mois minimum, pour conserver la qualité et l'efficacité de la batterie.**

IMPORTANT CONSIGNES DE SÉCURITÉ :

- CESSER immédiatement l'utilisation si les gants deviennent trop chauds.
- NE CONVIENT PAS A UN ENFANT.
- NE PAS CHARGER les articles HEAT CONCEPT AVEC UN AUTRE CHARGEUR que celui fourni.
- NE PAS INTRODUIRE d'objets métalliques ou autres dans les connecteurs ou prises, car cela risquerait d'endommager les articles HEAT CONCEPT.
- NE PAS APPORTER de modifications aux produits HEAT CONCEPT (gants ou couvre-chaussures).
- NE JAMAIS ENLEVER le film de protection des batteries vous risquez une explosion en cas de manipulation inappropriée des batteries polymère.

PROI

POUR NOUS CONTACTER

0 800 30 30 99 Service & appel gratuits



HEAT CONCEPT

THANK YOU FOR PURCHASING HEAT CONCEPT PRODUCTS.
READ CAREFULLY THESE INSTRUCTIONS BEFORE USE

CAUTION: IT IS IMPERATIVE TO USE ONLY THE CHARGER PROVIDED WITH THE PRODUCT TO CHARGE YOUR BATTERIES.

IMPORTANT START-UP :

- 1) It is necessary to fully charge the batteries before the 1st start.
- Connect the charger to an outlet (the LED charging indicator lights up **GREEN**)
- Then connect the 2 batteries to the charger, charging begins automatically and the charging light stays on while charging.
(The LED turns **RED** this indicates that your batteries need to be charged)
- 2) The charging time is approximately 2 to 4 hours depending on the level of battery charge.
- When the battery is fully charged, charging stops automatically and the charge indicator LED turns **GREEN** again.
- 3) Disconnect the batteries from the charger and reconnect the batteries at the gloves or cover-shoes connector, place each battery where provided and properly close the pocket.
- 4) Press the button for more than 3 seconds to turn the heating system on/off.

USE OF YOUR HEAT CONCEPT PRODUCTS :

We advise you to switch on in **GREEN LED** mode, your gloves without taking them 5 minutes before setting off so that the gloves are preheated and your hands are perfectly protected from cold from start to end of your ride.

Press more than 3 seconds to turn the heater on/off.

At half ride, switch to **ORANGE** mode (heat a little more intense than **GREEN** mode) and at the end of the ride when you feel that the temperature of the gloves is lower, switch to **RED** mode to finish with warm hands.



GREEN LED = MINIMUM HEATING
ORANGE LED = INTERMEDIATE HEATING
RED LED = MAXIMUM HEAT

As soon as you return, put your batteries back on charge.

WARNING :

In case of heavy rains, we advise you not to use the heating system.

Batterie charge %



4 red bars = 100%
3 red bars = 75%
2 red bars = 50%
1 red bar = 25%

2 years guarantee

Info BATTERIES :

- Batteries in lithium Polymere 7,4 V : LI -PO 2200 ah
- DCP : DC 8,4V 1200mA
- MAX output power 15W

BATTERY Storage:

- Store the batteries in a cool, dry place.
- Do not expose to the sun, or to a heat source
- Designed for 500 charge cycles
- Spare battery available -> Optional

INSTRUCTIONS TO READ CAREFULLY BEFORE USING CHARGER :

- Charger INPUT AC100 / 240 V (50/60 Hz-1.0A)
- OUTPUT DC8.4V / 1200 mA charger

- Removable rechargeable batteries (Supplied with main charger).

- **Remember to recharge them at least every 3 months to maintain the quality and efficiency of the battery.**

IMPORTANT SAFETY INSTRUCTIONS:

- IMMEDIATELY STOP use if the gloves get too hot.
- NOT SUITABLE FOR A CHILD.
- DO NOT LOAD HEAT CONCEPT items WITH ANOTHER CHARGER than the one supplied.
- DO NOT INTRODUCE metallic or other objects into connectors or sockets, as this may damage HEAT CONCEPT items.
- DO NOT MAKE any modifications to HEAT products CONCEPT (gloves or cover-shoes).
- NEVER REMOVE the battery protection. You risk an explosion if handled or improper use of polymer batteries.

PROI

POUR NOUS CONTACTER

0 800 30 30 99 Service & appel gratuits